


USpace 7250 Wall Box

Please read instructions carefully before installation

NB: Please ensure that the wall being used to hang the wall box on is level and sturdy enough to take the weight of the wall box and equipment being housed within. Should the surface not be level we strongly recommend packing be used – failure to do so is likely to mean the wall box will be distorted.

Step 1: Mark out and drill Hanging Bracket positions ensuring the Bracket is level.


NB The hanging bracket is designed to support the wall box during installation it also provides additional support when heavier loads are fitted within in wall box.



Step 2: Locate wall box onto hanging bracket. Mark out and drill hanging positions

Step 3a: Using appropriate fixings slide the wall box over the top two screws ensuring the wall box is level

Step 3b: Once the wall box is in its finished position fit appropriate fixings into bottom two holes. **NB:** The screw and washer should fit over the vertical slot and not the round hole.



	Dimension A	Dimension B	External Dimensions of box	
			Width	Height
12U	575.95mm	566mm	700mm	630mm
18U	842.65mm	566mm	700mm	897mm
21U	976mm	566mm	700mm	1030mm